



Instant Manual Download

# Pfaff Creative 7550 instruction manual

[Download Here](#)

Pfaff Creative 7550 instruction manual

- Accessories and needles 148
- Accessory compartment 20
- Adding stitches 99
- Activating the code (entering the code) 39
- Alphabet 64
- Alphabets/Monograms 62
- Alphabets/Monograms, summary 1 3
- Appliqu&eacute; foot 152
- Arrowhead bartack 1 22
- Automatic bartack 1 22
- Automatic darning 1 23
- Axial mirror image 45
- Balance 55
- Balance, buttonhole correction 1 39
- Balance for embroidering 1 68
- Balance, sideways stitch correction 56
- Basic menu (start-up menu) 46
- Basting stitch 11 5
- Battery message 38
- Bias tape binder 1 56
- Blind stitch 11 6
- Bobbin case 24
- Bobbin thread monitor 44
- Bobbin winding 2123
- Buttonholes 1 32
- Buttonholes with gimp thread 143
- Changing the battery 1 60
- Changing the letter width 63
- Changing the needle 32
- Changing the needle plate 161
- Changing the sewing foot 29
- Changing the sewing lamp 1 62
- Checking the bobbin thread tension 25
- Cleaning and oiling 161
- Cleaning the display 161
- Closed overlock stitch 118
- Closed overlock stitch with edge thread 118
- Connecting the foot control 1 9
- Cording foot 153154
- Covering seams 11 9

Creating a letter sequence 6567  
Creative Designer programming 87110  
Creative Designer, technical part 8990  
Cross stitch 11 9  
Cross stitch 1 70  
Cross stitch borders, pre-programmed 1 71  
Cross stitch embroidery 1 721 73  
Cross stitch, embroidery tips 1 70  
Cursor function 7678  
Cursor keys 45  
Darning with the elastic stitch 1 27  
Darning with the straight stitch 1 24  
Decorative elastic stitch 1 20  
Deleting a pattern in the M-Memory 7778  
Deleting a pattern in the P-Memory 102  
Deleting a stitch at the end/P-Design 101  
Deleting a stitch within a pattern 102  
Deleting letters 67  
Deleting programmed buttonholes 1 36  
Detachable work support 20

and a lot more

[Download Here](#)